

* SEE TYPICAL SECTIONS FOR THICKNESS AND MATERIALS

NOTES:

- 1. THE WIDTH OF THE FULL DEPTH PATCH OVER A TRENCH SHALL BE 12 (300) WIDER ON EACH SIDE OF THE TRENCH.
- 2. FOR METHOD OF MEASUREMENT AND BASIS OF PAYMENT, SEE RECURRING SPECIAL PROVISION "PATCHING WITH HOT-MIX ASPHALT OVERLAY REMOVAL".

SEQUENCE OF CONSTRUCTION

- 1. REMOVE THE EXISTING HMA MATERIAL OVER THE AREA TO BE PATCHED.
- 2. REMOVE AND REPLACE FULL DEPTH PATCHES
- 3. REPLACE HMA MATERIAL OVER THE AREA TO BE PATCHED.

ALL DIMENSIONS ARE IN INCHES (MILLIMETERS) UNLESS

REVISIONS		ILLINOIS DEPARTMENT OF TRANSPORTATION	
NAME	DATE	2000	**
R. SHAH	10/25/94		
R. SHAH	01/14/95		TOUTNO FOR
R. SHAH	03/23/95	HMA SURFACED	
R. SHAH	04/24/95		
A. HOUSEH	03/15/96		
A. ABBAS	03/21/97		
A. ABBAS	01/20/98		
ART ABBAS	04/27/98	SCALE: VERT. NONE	DRAWN BY
R. BORO	01/01/07	HORIZ.	
		PLOT DATE: 2/11/2008	CHECKED BY
			BD400-04 (BD-2

DY DATE = 2/11/2009 E. NAME = PivDistDetail-IL23/bd22.dgn DY SCALE = 54.600 '/ IN. ER NAME = shuramab